

# Presentation



#### LOU SIMONNEAU, THIBAUD BIZELDEAU

# The beginning.... materials !



TV



#### remote controller




repartitor



# Decoder

#### MEGASAT





#### **Rake receiver**

### **Coaxial cable**



### **HDMI Cable**



#### **Connector F**














# 1. Connections between

- realise all the connections with the cables (slide 4)
  - cable HDMI between decoder TNT and TV
- Coaxial cable between rake receiver and distributor
- -Coaxial cable between distributor and decoder TNT

## 2. Megasat in order to test the Rake Receiver

Connect the coaxial cable between rake receiver and the megasat. Then switch on and go on the spectrum to see the frequencies. Next, return to home menu for an autoscan.